



Satmaster Pro Mk9.x Quick Start User Guide

Satmaster Pro is designed to run on Windows XP/Vista/7/8. This is a quick start guide in using the software. More detailed technical Information is supplied in the help file distributed with the full product. Some functions described below may be disabled in demo versions. Satmaster Pro assumes the user has an outline knowledge of link budgets and the various parameters applicable.

For sales/support enquiries relating to this product please contact:

Arrowe Technical Services using the email contact form on any of the website URLs below.

<http://www.arrowe.co.uk>

<http://www.arrowe.com>

<http://www.satmaster.co.uk>

<http://www.satmaster.com>

Overview

Satmaster Pro is a general purpose tool for the satellite industry. Signal propagation, antenna aiming (including dual feeds), link budget analysis and solar outage prediction provide the backbone to the package. At the end of this document, a method is described where you may prepare paired carrier link budgets.

Other features, include integral magnetic variation calculation and tens of thousands of stored town/city co-ordinates for over 200 countries. All the non-file based input forms are pre-filled with example data, which you may customise.

Installation

CD Version: Insert CD into drive and open the drive folder. Double click 'setup.exe' and follow the simple on-screen instructions.

Web Demo Version: Download the self extracting file from the website and run it. Follow the on-screen instructions and respond to the prompts for destination hard disk folder etc.

The install program decompresses files to your hard disk and sets up a program

menu group containing Satmaster Pro. You run the program by double clicking the desktop shortcut or selecting from Windows main menu. Satmaster Pro is uninstalled using the “Add/Remove Programs” tool in the Control Panel.

Running Satmaster Pro

Satmaster Pro is designed to be simple to use and works just like any other Windows application with menus, speed buttons, dialog boxes (forms), windows, a status bar and an HTML help system.

The program starts with a main application window, menu and toolbar. The toolbar gives access to the File, Edit, View, Map, Graph, Table, Calculate, Option, Window and Help menus.

The data file types Satmaster Pro uses are:

- Look Angle Files (*.ang) – Antenna aiming.
- Dual Feed Files (*.duo) – Dual feed calculations.
- Link Budget (*.glb) – GEO full up-down digital link budget (bent-pipe)
- Country Files (*.twm) – Country files with town/city data
- Satellite File (*.geo) – The GEO satellite list
- Solar Outage (*.sun) – Sun outage results file
- Bitmap Files (*.bmp;*.gif;*.pcx;*.tif;*.jpg) – Footprint maps etc.
- Rain Attenuation Files (*.atn) – Rain attenuation data files
- Regenerative Uplink Budget (*rup) – Digital budget for regenerative transponder uplinks (GEO or NON GEO supported).
- Regenerative Downlink (*rdn) – Link budget for regenerative transponder downlinks (GEO or NON GEO supported). This module may also be used for quick TVRO antenna sizing where a bent pipe transponder is operated near saturation,
- Link Budget (Non GEO) (*llb) – Link budget for HEO/MEO/LEO satellites (bent-pipe)
- Batch GEO Link Budget (*mlk) – Control file for batch link budgets.
- Two Line Element Files – NORAD TLE files (*.tle)

You may open any mix of these file types (memory permitting). You can display many windows simultaneously to compare different links and their performance characteristics.

The database files, (*.geo) and (*.twm), are fully editable and may be modified or appended by the user at any time. To save time the latest file ‘satlist.geo’ can also be downloaded from our web site.

System Clock

Ensure the date of your system clock is correct, so current magnetic variation values may be calculated. It should be noted that the best possible accuracy, using any global model, is + or - 0.25 degrees.

Data Conventions

Satmaster Pro requires the following rules to be observed when entering or interpreting values of latitude, longitude or magnetic variation. All units are degrees unless otherwise stated.

- Latitudes NORTH suffixed by N (eg 53.33N)
- Latitudes SOUTH suffixed by S (eg 10.34S)
- Longitudes EAST suffixed by E (eg 19.2E)
- Longitudes WEST suffixed by W (eg 3.1W)
- Magnetic variation EAST suffixed by E (eg 3.0E)
- Magnetic variation WEST suffixed by W (eg 3.0W)

Latitudes and longitudes, are usually obtained from maps and atlases in degrees & minutes format, whilst satellite longitudes are often quoted in decimal degrees. When using Satmaster Pro, always use decimal degrees for all input fields with the exception of editing country files outlined below.

A convenient conversion facility is provided under the “Calculate” menu to convert from the degrees and minutes form to degrees.

When editing country data files it is more convenient to enter and check data in degrees and minutes format. Satmaster Pro automatically converts degrees and minutes format to decimal degrees as and when the data is used.

Help Facilities

A help system is employed using a variety of methods listed below:

- Each dialog box (form), has its own help button which may be clicked to display detailed information about input values.
- Press F1 key for context sensitive help on any input field.
- Click the 'question mark' (?) button on top right of a form then click the field of interest.

Input Forms

Satmaster Pro makes heavy use of input forms (dialog boxes). This makes input validation comprehensive and allows the user to call up help as necessary for assistance with range, type and definition of input parameters. All input is validated in an attempt to make the program ‘crash-proof’ and rejects bad input data where possible.

You may cancel (close) a partially completed form at any time and provided you do not close it's associated window, data will be retained on clicking the “Edit Active Document” button again. You may also save incomplete forms.

Toolbar

The toolbar buttons duplicate the more frequently used menu selections. The most useful is the ‘Edit Active Document’ button, third from left, It saves a lot of menu thrashing! The toolbar supports the yellow “tooltips”. In order, left to right, the buttons represent:

Load an existing file; Save file; Edit active document; Copy all; Print; Print preview; Tile open windows; Cascade open windows; Help.

Getting Started

Here is a summary of using Satmaster Pro.



Edit Active Document toolbar button.

For any file type, either new or opened, bring up the input form by clicking the “Edit Active Document” button shown above, complete the form then click it’s OK button to calculate. Provided you do not close the associated window, you may also leave any, file based, input form at any time without losing partially completed data by clicking the Cancel button. To restore the form click the “Edit Active Document” button again. The edit button, shown above, is easily the most useful, and convenient, button on the toolbar. You can edit any file window, at any time, by clicking this button. Pressing the “F12” hot key performs the same action.

Default parameter sets are not necessary, simply load a parameter file that is closest to that needed, edit the parameters that are different then save it under a different file name This is much quicker than starting with a new blank file.

When a report, footprint, graph or table is displayed in an active window, simply click the “Copy” button to transfer the entire contents to the clipboard in a single operation. The clipboard contents can subsequently be pasted into a spreadsheet with minimal editing.

Satmaster Pro can also read BMP, TIFF, PCX and JPEG formats, which may be useful to display EIRP, G/T and SFD footprints (for copyright reasons these are not redistributed with Satmaster Pro).

Options Menu

The first thing to do is enter your company name into the Set-up dialog box. This text is inserted in all printouts and displays.

- Click on 'Options' from the menu bar then select 'Setup'. The persistence of the set-up data is selected using one of three "Persistence" radio buttons shown below.
- 'This session only' - any changes made to the set-up dialog are temporary and last only for the duration of the current session.
- 'All sessions' - any changes made to the set-up dialog take effect immediately, as above, but are also saved to disk as the file 'satmast.cfg'. Next time you run Satmaster Pro, these values and selections will be restored.

'Restore defaults' - this restores the default settings when you first installed Satmaster Pro. Checkboxes are provided for saving all data present in the input forms under the Table, Graph and Calculate menus

File Menu

Use this option to save, open, print, or create new files. There are many different file types. If you select File|New the appropriate form is displayed for the file type selected. Simply complete it referring to Help where necessary.

To open an existing file select 'File|Open' to display the open dialog then select the file type from the 'List Files of Type' section.

Editing Files

The following sections show how to produce a selection of files followed by how to create and edit the country and satellite databases. Creating and editing any other file type follows the same method.

Look Angle Files (*.ang)

This file type is used to calculate antenna installation settings. Click on File|New then select "New Look Angles" from the menu to display an empty 'Look Angles' window and input form. Later you may probably find it more convenient to amend a previously saved file and just alter the parameters for your particular location. Remember to save it under a different filename though.

For convenience, you may transfer data from the country town/city database into the 'Look Angles' form with the 'Site' button. Clicking this button will bring up an 'Open Country Data File' dialog for you to select a particular country file.

Entering a letter from the keyboard can quick scroll the list box to the appropriate alphabetical point.

Once the country file has been selected, a list box is displayed for you to select a town or city from the file. Entering a letter from the keyboard scrolls the list box quickly to the appropriate alphabetical point.

Similarly, data from the satellite database file 'satlist.geo' may be transferred into any dialog equipped by clicking the 'Satellite' button and double clicking on the required satellite in the list box. Again, entering a letter from the keyboard can quick scroll the list box.

When you have completed the 'Look Angles' dialog click the OK button to trigger the calculation. You may also close the input form without losing any entered data by clicking the 'Cancel' button provided you do not close the associated display window. By reactivating the accompanying window and either selecting 'Edit Active Document' from the 'Edit' menu or clicking the toolbar button you may finish entering your data. This facility is also applicable to all the link budget and solar outage forms.

Once you have triggered the calculation, the associated window displays the calculated data and the parameter file may be saved with the 'ang' extension. To do this, select 'Save As' from the 'File' Menu which displays the appropriate dialog box and enter a filename. It should be pointed out, that only the input parameters are saved, not the text itself. If you wish to save the text portion as a simple text file then select 'File|Save As Text' or 'File|Save as HTML'. You may also copy the text to the clipboard, as 'tab delimited text', for directly pasting into a spreadsheet or similar application.

Link Budget Files

There are several types of link budget file. The regenerative downlink module has a dual purpose. It may also be used for quick TVRO antenna sizing providing the bent pipe transponder is operated near saturation. Obviously, by performing a downlink calculation in isolation you need to make a few assumptions, but for broadcast TV reception, the error is small and adequate for sizing downlink antennas. For satellite TV, the uplink side uses UPC (uplink power control) or ALC (automatic level control) in an attempt to reduce the effects of uplink rain on the downlink.

The procedure for editing and completing link budget forms is similar to that of the 'Look Angles' example. Simply complete, referring to Help as necessary then click the OK button to trigger the calculation.

On all link budget forms, there is an option to enter either antenna efficiency or gain. To enter a gain prefix the value entered with a '+' character. This option is useful where the gain of the antenna is already known. Likewise you can choose whether to enter an LNA/LNB noise figure or noise temperature. To enter a noise temperature prefix the value entered with a '+' character.

The rain models are fully automated, no reference maps are required. ITU-R P618 rain model is used throughout.

Some isolated downlink budgets have options for optimising for a minimum receive antenna size. It should be realised that the adjacent satellite interference (ASI) will also increase as the antenna size reduces. When the "Antenna Size Optimisation" tab is clicked it allows you to select the type of antenna size optimisation to adopt as shown above. With small dishes the level of ASI is often more dominant than power requirements for determining the minimum antenna size.

Link Budget Files (GEO)

Use this module for the vast majority of digital link budgets. It performs up-down link budgets for VSAT networks, digital links for SNG as well as most other applications. This module can iterate the link budget for minimum uplink power requirements.

To use this module open a new digital uplink file or, perhaps easier, modify an existing file. Complete the form referring to 'Help' as necessary. Under the 'Graph' menu there is a reference chart to obtain values for Eb/No for various code rates and modulation schemes.

Click the tabs to select portions of the form. The overall design relies only on information easily available or estimated.

There is "Reverse" button on the input form which toggles (exchanges) some site dependent input parameters from the uplink to the downlink. This can save some typing when a link budget needs to be performed for the reverse link in a network situation.

Under the "Carriers and Modulation" tab you can select from BPSK (1 bit/symbol), M-PSK or M-QAM modulation. If 1bit/symbol is selected always enter M=2 since it is a binary signalling system.

Other Link Budget Files

With the non-geo satellite link budgets you will need a figure for range and elevation to create a "snapshot" link budget. Otherwise operation is very similar to those already described. Remember to press F1 on any input parameter for help.

Common Causes of Failure to Balance a Link Budget

There are three main reasons why negative margins or failure to balance a link budget may occur while using Satmaster Pro.

1. With digital link budgets, ensure you have entered the information rate in units of Mbps not kbps. This is a common mistake.
2. Entering an excessive signal availability value. If in trouble always start off with a low availability of, say, 99.3% and work upwards.
3. Entering too lower a value for interference fields. The lower the numerical value entered, the higher the interference.

Dual Feed Files

These files are similar to look angle files but also calculate the relative satellite spacing and (x,y) feed mounting positions for dual feed systems. You can use the resulting antenna efficiency reduction to perform a second link budget if need be. Repeat as often as necessary for multiple feed systems.

Rain Attenuation Files

This module calculates the attenuation, system noise increase and downlink degradation due to rain for any given slant path. As with all the link budget modules a choice of using either the ITU or Crane model is catered for.

Solar Outage Files

Twice a year the sun crosses the equator and traces an arc that is directly behind the geo-arc of satellites. Noise from the sun, within capture of the antenna's beamwidth, disrupts reception. The effect is known as a solar outage.

Satmaster Pro employs a complex algorithm to calculate the sun's position rather than rely on approximation methods. Events are listed in date order and grouped into early and late seasons.

Sun files (*.sun) are used to store solar outage input parameters. Completing a solar outage form is similar to that of previous examples, the parameter files can be opened and saved in a similar manner.

Within the edit dialog select either 'standard' or 'wide' beamwidth. The region of sky scanned depends on the specified antenna beamwidth of the receive station. If an even wider 'window' is required, reduce the antenna diameter parameter to increase the beamwidth. The default prediction is accurate to the 'nearest minute', however there is a 'nearest second' option.

Clicking the 'OK' button starts the calculation, which may take some time calculating with slower processors.

Note: If the program does not find any outages, the most likely reason is that the time zone entered, relative to the Greenwich meridian, is incorrectly input. Time zones west of the Greenwich Meridian are entered negative and time zones east, positive. Do not include any 'daylight saving' schemes in this.

How to Edit Country Data Files

Country data files contain latitude and longitude site co-ordinates for major towns and cities. There are about 250 country files with up to 1800 entries in each. This data can be used either to edit forms equipped with a 'Site' button or generate various tables such as 'International Look Angles' under the 'Tables' menu. Select 'File|New|New Country Data' to start a new file, you may want to create a custom list of earth stations you regularly link with.

To edit an existing country file:

1. Click 'File' then 'Open'. The Open dialog is displayed.
2. Select 'Country Files (*.twm)' from the 'List Files of Type' pull down listbox.
3. Select the file of the country of interest (e.g. United Kingdom.twm). A window should appear containing a list of all the towns and cities currently stored.
4. Click the toolbar edit dialog button or select 'Edit Active Document' from the 'Edit' menu. The 'Edit Town/City Data' dialog appears (shown below).
5. Click on the name of the town/city you wish to amend then click the modify button (double clicking on the town/city goes straight to modify). The 'Modify Town/City Record' dialog appears. You can also change the name of the country as it appears on reports and printouts by clicking the 'Edit Country

Name' button.

6. Edit the Town/City name and co-ordinates as necessary then click the 'Done' button.

Modify town/city records by clicking the 'Modify' button or add records by clicking the "Add" button. Click the "Done" button after modification then save the file using 'File|Save As' from the program's menu.

How to Edit Satellite Data File

A database of geo-stationary satellites, their locations and active bands are stored in a single file called 'satlist.geo'. Select File|Open then select 'Satellite File (*.geo)' from the 'list files of type' drop down list box in the 'Open' file dialog. Select the file 'satlist.geo' and its contents will be displayed in a window. Click the edit toolbar button to edit in a similar manner to the town/city files. This file is used with the 'Satellite' button in many input forms and to generate lists of satellites 'visible' from a chosen location.

Display Footprint Maps (*.bmp; *.gif; *.tif; *.jpg)

Footprint maps (not included in the package for copyright reasons) may be opened by selecting 'File'|'Open' then listing 'Bitmaps *.*' in the 'Open File' dialog. A more convenient way is by selecting 'Map|Display Footprint Map' from the menu bar.

Footprint maps may be obtained from satellite operator's web sites or scanned from any publication you wish. Also many independent web sites have a large collection of EIRP footprints such as <http://www.satbeams.com>. Satmaster Pro will display BMP, GIF, TIFF and JPEG formats.

Map Menu

There are two reference diagrams under the 'Map' menu, one is called 'Polar Mount Diagram' and the other is 'Polarization Offset Diagram'. These diagrams clarify the angle terminology used. There are also reference maps for time zones and ITU regions.

Graph Menu

The 'Graph' menu allows you to plot various relationships between parameters and may be useful for reference purposes. Select the required graph from the 'Graph' menu and fill in the corresponding form. Any data entered into these forms are persistent. If you do not need the current data then click the input form's 'Clear' button. Context sensitive help is available on all fields. Each graph is plotted in a new window and may be either printed out or copied to the clipboard. The graphs show general trends, they are not intended for accurately extracting values.

Table Menu

Select the required table from the 'Table' menu, fill in the displayed form associated with it and click the OK button. As described in the previous section

entered data can be persistent. The table of results is displayed in a new window and may be either printed, saved as an unformatted text or HTML or copied to the clipboard as tab delimited text. The status bar also displays the order of the table columns. This may be helpful if the table headings are scrolled out of view

Particularly useful options under the 'Tables' menu are 'International Look Angles' and 'Dual Feed Spacing'. For all major towns and cities in a selected country, the former builds a table of look angles to a particular satellite and the latter a table of relative satellite and feed spacing. A further useful table is 'Satellites Above Horizon' which generates a table of look angles for all satellites 'visible' from a particular site.

Solar Event Tables

There are two types of solar event table generated by selecting from the 'Table' menu. The first is 'Solar Transit Times' and the second is 'Sun/Satellite Azimuth Coincidence'. The former is useful for accurately locating true north/south for installing polar mount antennas when using the 'stick in the ground' shadow method. The latter may be useful for locating the true azimuth of a satellite if a compass is not to hand or local magnetic fields are affecting it's reading. Both tables share the same "Edit Solar Event Form' dialog shown below.

The input form entry in need of further explanation is labelled 'Solar transit or satellite longitude'.

If you require a table of solar transit times, this entry should be identical to that entered for the site longitude. That is to say, the times are calculated when the sun crosses the site's local meridian. This can be thought of as the longitude of a "virtual" satellite directly south of your location (north in the Southern Hemisphere).

On the other hand, if you require a table of times when the sun's azimuth is the same as that of a target satellite, from your location, then that satellite's longitude or orbital slot should be entered instead. Satmaster Pro will automatically detect which has been entered and display the appropriate table.

Calculate Menu

Here there are several modules to perform commonly required calculations and conversions such as, noise temperature to noise figure, degrees and minutes to degrees, wavelength to frequency etc. Click 'OK' button to recalculate or 'Cancel' to terminate.

Expression Evaluator

The expression evaluator (under the 'Calculate' menu) allows you to evaluate a mathematical expression entered as a string of characters to a numerical result.

The operator precedence is as follows

- Negate
- * Multiply
- / Divide

Satmaster Pro User Guide

+	Add
-	Subtract
^	Raise to the power

You may override the normal operator precedence with parentheses. For example: $f=(b+c)/a$ forces $b+c$ to be evaluated before dividing by a .

The following functions are supported; the arguments must be enclosed in parentheses. For example $\sin(45)$. With trigonometric functions, you can select either degree or radian mode by selecting the appropriate radio button.

abs	absolute value
acos	arc cosine (inverse cos)
asin	arc sin (inverse sin)
atan	arc tan (inverse tan)
cos	cosine
cosh	hyperbolic cosine
exp	exponential
log	logarithm (base 10)
logt	logarithm (base 2)
ln	logarithm (base e)
sin	sine
sinh	hyperbolic sine
sqr	square root
tan	tangent
tanh	hyperbolic tangent

The constant 3.14159258 is entered into an expression as either 'pi' or 'p'.

Window Menu

This menu helps you organize the application's windows. Choosing 'Cascade' arranges all open windows in a staggered and overlapped fashion. Choosing 'Tile' shrinks and arranges all open windows into a tile design either vertically or horizontally as requested. If 'Arrange Icons' is selected it tidies up and arranges all the minimized icons at the bottom of the main application window. 'Close All' closes all open windows and leaves a clear application window. There are also toolbar buttons for 'Cascade' and 'Tile Vertically'.

Help Menu

Selecting "Help Contents" offers more detailed information on how to use Satmaster Pro and background information on various technical and practical topics.

Copying Output to Spreadsheet Programs

The entire contents of any window may be copied to the clipboard in a single operation as tab delimited text. Selecting "Edit|Copy" or clicking the toolbar's copy button initiates this process. Output can then be pasted directly into a spreadsheet application, such as Excel, for quick customisation without re-formatting.

Drag and Drop

Satmaster Pro supports the drag and drop standard of loading its file types into the main application windows. Windows shell features, such as “open” and “print” are enabled.

Most Recently Used Files

Under the ‘files’ menu there is a list of the six most recently used files. This enables quick opening of any of these files without the need to bring up the open file dialog.

Feedback to Author

Satmaster Pro is often improved. Your comments, criticisms and suggestions are always helpful. If any errors are detected please let me know. Contact details are at the head of this document.

How To Prepare Paired Carrier Link Budgets.

This type of link budget may require a special mention as it differs significantly from regular link budgets. Paired Carrier is an adaptive cancellation technology that allows two carriers to simultaneously occupy the same transponder bandwidth. Paired carriers are affected by the same interference and atmospheric factors as normal carriers. Although up to 50% reduction in bandwidth usage would appear possible, this is not strictly true since there is an extra degradation, associated with each of the pair, due to interference between the two. That aside, significant bandwidth savings are possible by using paired carrier technology. Link budgets using this technology can be prepared using Satmaster Pro by using the following guide.

1. Using File|New from main menu, open two Link Budget instances so you have a separate link budget for each direction inbound and outbound to hub.
2. Enter all the usual link budget (LB) input parameters paying special attention to the 'Implementation loss' input field under the 'Carriers' tab. Your modem manufacturer may supply guidance on the relevant values to enter for the extra degradation to be expected with paired carrier arrangements.
3. Screen resolution permitting, you may arrange the two link budget windows, inbound and outbound, side by side using 'Window|Tile Vertically' from the main menu.
4. The balancing of the two link budgets is a manual iterative process which is dependent on the initial results. A number of parameters (G/T, FEC and modcod) may be changed in an attempt to make the link more bandwidth limited and less power limited.

Satmaster Pro User Guide

5. Whenever a change is made then the two link budgets are run again to check the wanted to interferer beam peak power spectral densities are within ± 7 dB of each other and the symbol rate ratio of the two carriers should be a maximum of 3:1 or 1:3 .There is an optional input for transponder EIRP beam peak so that the carrier beam peak values for PSD and EIRP are calculated